



Terpolymerization Kinetics in Successful Scale-up of The Solution Polymerization of Ethylene and Styrene

Brian W. S. Kolthammer,
Thomas W. Karjala, Frank J. Cerk

Performance Plastics Technology
The Dow Chemical Company
Freeport Texas






Background


Dow Discovered Catalysts to Copolymerize Ethylene & Styrene in 1989

- Improved Flexibility, Abrasion Resistance, Toughness, Printability, Creep, Compatibility
- Semi-Crystalline (<13 mol% Styrene) to high T_g Glassy (50 mol % Styrene) Products




Successfully Scaled Up from Batch to Mini-plant to Pilot Plant to Semi-Commercial Scale

- Commercialization of INDEX™ Interpolymers in 1998
- Stopped Production at Sarnia Product Development Plant in 2002 for Economic Considerations





Solution Polymerization Process






Well-Mixed, Steady-State Reactor
Uses Heat to Devolatilize Polymer
Need to Pelletize, Convey, and Store Product





Practical Copolymerization Models

Ratios of Monomer Polymerization Rates



$$R_{p1} = k_{11}N_1C_1 + k_{21}N_2C_1$$

$$R_{p2} = k_{12}N_1C_2$$

Apply Two Simplifying Assumptions

- Long Chain
 - Neglect Effect of Chain Length on Propagation Rate
 - Neglect Initiation and Termination Reactions
- Steady State Hypothesis for Growing Chains
 - Rate of Production = Rate of Consumption

Reactivity Ratios Are Ratios of Propagation Rate Constants

$$r_{ij} = \frac{k_{ii}}{k_{ij}}$$


$$r_s = \frac{k_{21}}{k_{23}}$$





Experimentation at Small Pilot Scale


- 2 kg/h Production Rate
- Single Pass, Continuous Well-Mixed Reactor
- Calibrated Flowmeters
- Analysis of Key Streams
 - Vapor, liquid
 - Polymer
- Proper Experimental Design






D-optimal Design for E-S Copolymerization

The D-optimal Criterion:
$$|\mathbf{F}^T \mathbf{F}| = \left(f_2 \frac{1 - f_2}{(2f_2 + r_{12}(1 - f_2))^2} \right)^2$$






Kinetic Model Scale-Up to Semi-commercial



Challenges of Styrene Monomer

Tendency to auto polymerize

- Stabilizer (4-tert-butyl catechol)
Poisons Catalyst
- Undesirable Thermal Polymerization of Styrene during Reactor Loading and Start-up



Careful Reactor Startup/Shutdown Methodology Required


- Control Crystallinity of Polymer to Avoid Process Fouling due to Reactor Temperatures Below Polymer Freeze Point
- Minimize Inventory of Styrene in Recycle System

$$R_i = k_d [M]^3$$



Eliminating Excessive Polystyrene Formation

- Avoid High Styrene Concentrations in Process
 - Process not Designed to Handle Polystyrene
 - Plugging of Devolatilization and Material Handling Systems
 - A Method for Controlled Introduction of Styrene
- Use Propylene as a Safe Substitute
 - Control Polymer Composition During Transient Operation
 - Maintain Operability During Shutdown/Startup
 - Need an E/P/S Terpolymerization Model





Ethylene/ Styrene/ Propylene Terpolymerization

Characterize Gross Composition with up to Five Reactivity Ratios and Two Equations

- (Ignore Reverse Insertion of Styrene and Propylene)

$$\frac{F_2}{F_1} = \frac{f_2 \left(\frac{f_1}{r_{12}r_{31}} + \frac{f_3}{r_{13}r_{32}} + \frac{f_2}{r_{12}r_{32}} \right) \left(f_1 + \frac{f_3}{r_s} \right)}{f_1 \left(\frac{f_3}{r_{31}r_s} + \frac{f_1}{r_{31}} + \frac{f_2}{r_{32}} \right) \left(f_1 + \frac{f_2}{r_{12}} + \frac{f_3}{r_{13}} \right)} \quad \frac{F_3}{F_1} = \frac{f_3 \left(\frac{f_1}{r_{31}} + \frac{f_2}{r_{32}} + f_3 \right) \left(\frac{f_2}{r_{12}r_s} + \frac{f_1}{r_{13}} + \frac{f_3}{r_{13}r_s} \right)}{f_1 \left(\frac{f_3}{r_{31}r_s} + \frac{f_1}{r_{31}} + \frac{f_2}{r_{32}} \right) \left(f_1 + \frac{f_2}{r_{12}} + \frac{f_3}{r_{13}} \right)}$$


D-Optimal Design

- Five Parameters – Minimum of 5 Experiments
- Numerical Simulation Necessary
 - Maple™ For Analytical Jacobian
 - Excel™ Solver for Optimization of Conditions






Desired Product Profile Through Shutdown and Startup






Startup Example – Reactor Feed Flows






Startup Example – Feed Concentrations






Startup Example – Reactor Concentrations






Startup Example – Product Composition





Shutdown Example – Reactor Feeds


Sarnia PDP: EPS Shutdown and Auto Styrene Burnout - Reactor Feed Concentrations





Shutdown Example – Product Composition

Sarnia PDP: EPS Shutdown - Product Composition





Conclusions

- Importance of Experimental Design
 - Inefficient Experimentation Wastes Time and Money
 - No Amount of Sophisticated Data Analysis Can Recover Information Not Present in a Dataset
 - The Correct Experimental Design Dictated by Mathematical Structure of Model
 - Carefully Designed Experiments Can Result in Greatly Increased Accuracy
- Practical Value in Reaction Engineering
 - An Accurate Kinetic Model is Available for the Terpolymerization of Ethylene, Styrene, and Propylene
 - A Good Kinetic Model is Critical for Efficiency and Cost-effective Operation at Commercial Scale

